

## UPDATE YOUR AT MODULE

## **KB-TZ2** and **KB1**

Add the new KB-TZ2 and KB1 specifications to your AT Module SI-AT-22 to help install each of these new anchors for the necessary pre-tension.

## Instructions:

Scan each QR code of the corresponding anchor you'd like to upload into your AT Module by using the module's scan function, just as you would to scan the barcode on the product box.







3/8" KB-TZ2 CS

1/2" KB-TZ2 CS



5/8" KB-TZ2 CS



3/8" KB-TZ2 SS304



1/2" KB-TZ2 SS304



5/8" KB-TZ2 SS304



3/8" KB-TZ2 SS316



1/2" KB-TZ2 SS316



5/8" KB-TZ2 SS316



3/8" KB1 CS



1/2" KB1 CS



5/8" KB1 CS