

- 1. Space powder—actuated fasteners accordingly to accommodate design loads.
- 2. Powder—actuated fasteners shall be installed IAW Hilti installation instructions.